

Before first use:

- Inspect product carefully before use. Wash and rinse each part separately and thoroughly

Cleaning and care instruction:

- This product may be cleaned by hand with gentle detergent or in a dishwasher on top rack only.
- After each use, separate all the parts, wash and rinse thoroughly
- Avoid using abrasive pads or cleaners and do not clean with, or allow coming into contact with solvents or harsh chemicals, as these could cause damage to this product.
- Excessive concentrations of detergents may in the long run, cause the breakdown of plastic accessories. If this happens, replace them immediately.
- Always wash the product immediately after each use.
- Do not boil, steam or microwave sterilise.

For your child's safety and health:**WARNING!**

- Always use this product with adult supervision
- Always check food temperature before feeding.
- Always check the temperature of food before offering to your baby.
- Before each use, inspect the product thoroughly. Throw away at the first sign of damage or weakness.
- Do not bend or twist.
- Keep all components not in use out of children's reach.
- Not suitable for use in a conventional oven or a combination microwave oven with grill feature.
- Always stir heated food to ensure even heat distribution and test food temperature before serving
- Do not store in direct sunlight or near heat source.
- Food colourings may discolour components but will not affect performance safety of the product.

**Please read the instructions carefully and keep the packaging for future reference.
Safety tested - Compliance with EN 14372.**

Imported and distributed by:

Anteprima Brands International Ltd,
1, Ferris Bldg, St. Luke St,
PTA1020, Gwardamangia,
Malta - Europe