

## Before first use:

• Inspect product carefully before use. Wash and rinse each part separately and thoroughly

## Cleaning and care instruction: This product may be cleaned by hand with

- gentle detergent or in a dishwasher on top rack only.
- After each use, separate all the parts, wash and rinse thoroughly
- Avoid using abrasive pads or cleaners and do not clean with, or allow coming into contact with solvents or harsh chemicals, as these could cause damage to this product.
- Excessive concentrations of detergents may in the long run, cause the breakdown of plastic accessories. If this happens, replace them
- immediately. · Always wash the product immediately after each use.
- · Do not boil, steam or microwave sterilise.

## For your child's safety and health:

- WARNING! · Always use this product with adult supervision Always check food temperature before
  - · Always check the temperature of food before offering to your baby.
  - · Before each use, inspect the product thoroughly. Throw away at the first sign of
  - damage or weakness. Do not bend or twist.
  - . Keep all components not in use out of
  - children's reach. · Not suitable for use in a conventional oven or a combination microwave oven with grill
  - · Always stir heated food to ensure even heat distribution and test food temperature before servina
  - . Do not store in direct sunlight or near heat
- source. · Food colourings may discolour components but will not affect performance safety of the product.

Please read the instructions carefully and keep the packaging for future reference. Safety tested - Compliance with EN 14372.

Imported and distributed by: Anteprima Brands International Ltd, 1. Ferris Blda. St. Luke St. PTA1020, Gwardamangia, Malta - Europe