



- Care & use:
 - ◇ Clean the product thoroughly before first use with warm water and mild detergent.
 - ◇ Always wash immediately after each use.
 - ◇ Do not clean or allow to come into contact with solvents or harsh chemicals. This could result in damage.
 - ◇ Avoid using abrasive pads or cleaners.
 - ◇ Dishwasher-safe (top rack only).
 - ◇ Maximum recommended water temperature to pour into the warming plate is 60°C (or 140°F)
- **For your child's safety and health: WARNING!**
 - ◇ Before each use, inspect the product thoroughly. Throw away at first sign of damage or weakness.
 - ◇ Always check the temperature of the feed before offering to your baby.
 - ◇ Always supervise your child during feeding.
 - ◇ Not suitable for use in a conventional oven or a combination microwave oven with grill feature.
 - ◇ Do not store in direct sunlight or near heat source.
 - ◇ This product is microwave safe for short periods only; do not use this item in the microwave for longer than 2 minutes at a time. When using a microwave the outside of the product will feel cooler than the food.
 - ◇ Always stir heated food to ensure even heat distribution and test the food temperature before serving
 - ◇ Keep all components not in use out of children's reach
 - ◇ Do not fill with boiling liquids or solids
 - ◇ Food colourings may discolour components but will not affect performance safety of the product.
- **How to use the warm plate:**
 1. Open the lid.
 2. Pour water into the water tank.
 3. Close the lid.
 4. Pre-warm the food and put it in the plate and the warm water will keep it warm.
- Please read the instructions carefully and keep the packaging for future reference.
- **Safety tested - Complies with EN14372**